



Mounting Guide

ECL Comfort 210, A230 (code no. 087H3802)


A230.1a:




A230.1b:




A230.1c:




A230.1d:




A230.2a:




A230.2b:



A230.2c:



A230.2d:




Mounting Guide ECL Comfort 210, A230

230 V a.c.

 **A230.1**

 **A230.2**




24 V a.c.

 **A230.1**


 **A230.2**

ECL 210/24 V a.c.




Mounting Guide ECL Comfort 210, A230


24 V a.c. / 230 V a.c. safety thermostat





 Pt 1000 (1000 Ω / 0 °C), S8
A230.1



 Pt 1000 (1000 Ω / 0 °C)
A230.2




A230.2






Mounting Guide ECL Comfort 210, A230

ECA 30 / 31



Master / slave



* 0 8 7 H 9 0 1 6 *



* V I L G I 1 0 0 *



ECL Comfort 210 / A230: <http://den.danfoss.com/>